

The StockMaster NavigatorPro includes StockMaster Auto-Gate to provide automatic protection

StockMaster Auto-Gate protects against the risk of falls from the front of the platform. As a person enters the platform the gate automatically moves to the closed and locked position. Releasing the lock permits exit from the platform. The gate then automatically re-sets to the open position for entry of the next user, improving safety and productivity and decreasing the risk of accident claims.



The StockMaster NavigatorPRO also includes StockMaster Rota-Gate for easy access to many jobs

StockMaster Rota-Gate opens the side of the platform railing for easy stock picking and access for manufacturing, maintenance and many other tasks. Place the ladder side on to the work-face. Unlock and rotate the gate the open position. Complete the task, return the gate to the closed position and re-lock it.

